

## BODY CONTROL MODULE (BCM)

Fuse	Amps	Circuits protected
F1	-	Not used
F2	10	Driver door window control switch Power sliding rear window switch Auxiliary switches Roof opening panel motor assemblies Sunshade module Direct Current/Alternating Current (DC/AC) inverter - early production Alternating Current (AC) power outlet socket (I/P) - early production Alternating Current (AC) power outlet socket (Center console) - early production Alternating Current (AC) power outlet socket (Box) - early production
F3	7.5	Wireless Accessory Charging Module (WACM)
F4	20	Not used
F5	-	Not used
F6	10	Driver door window control switch
F7	10	Gear Shift Module (GSM)
F8	5	Telematics Control Unit (TCU) module
F9	5	Intrusion sensor
F10	-	Not used
F11	-	Not used
F12	7.5	Heating, Ventilation and Air Conditioning (HVAC) control module Gateway Module A (GWM)
F13	7.5	Instrument Panel Cluster (IPC) Steering Column Control Module (SCCM)
F14	15	Not used
F15	15	SYNC module [APIM] Audio control panel
F16	-	Not used
F17	7.5	Headlamp Control Module (HCM)
F18	7.5	Not used
F19	5	Headlamp switch