

BODY CONTROL MODULE (BCM)

Fuse	Amps	Circuits protected
F20	5	Ignition switch Key release interlock actuator
F21	5	Trailer brake control switch
F22	5	Not used
F23	30	Driver Door Module (DDM)
F24	30	Roof opening panel motor assemblies Sunshade module
F25	20	Not used
F26	30	Passenger Door Module (PDM)
F27	30	Not used
F28	30	Audio Digital Signal Processing (DSP) module
F29	15	Adjustable pedal control switch Display unit
F30	5	Not used
F31	10	Radio Transceiver Module (RTM) All Terrain Control Module (ATCM) Driver status monitor Camera module (CMR)
F32	20	Audio front Control Module (ACM)
F33	-	Not used
F34	30	Ignition relay
F35	5	Direct Current/Alternating Current (DC/AC) inverter Alternating Current (AC) power outlet socket (I/P) - late production Alternating Current (AC) power outlet socket (Center console) - late production Alternating Current (AC) power outlet socket (Box) - late production
F36	15	Auto-dimming interior mirror Heated rear seat module Steering Column Control Module (SCCM) Steering Angle Sensor Module (SASM)
F37	20	Image Processing Module A (IPMA)
F38	30 circuit breaker	Rear door window control switch LH Rear door window control switch RH