

BATTERY JUNCTION BOX [BCMC]

Fuse	Amps	Circuits protected
F11	30	Starter motor
F13	40	Blower motor control module
F15	25	Horn
F19	20	Heated rear seat module Snowplow package
F21	10	Headlamp assembly LH Headlamp assembly RH
F22	10	Power Steering Control Module (PSCM)
F23	10	Anti-lock Brake System (ABS) module
F24	10	Secondary On-Board Diagnostic Control Module C (SOBDMC) Powertrain Control Module (PCM) Glow Plug Control Module (GPCM) Transmission Control Module (TCM)
F25	10	High mounted stoplamp assembly Generator (secondary) Trailer tow connector Rear parking aid camera
F28	50	Anti-lock Brake System (ABS) module
F29	50	Anti-lock Brake System (ABS) module
F30	40	Front seat control switch LH Driver front Seat Module (DSM)
F31	30	Front seat control switch RH
F32	20	Media bin power point 1
F33	20	Media bin power point 2
F34	20	Seat power point Rear console power point