

BATTERY JUNCTION BOX [BCMC]

Fuse	Amps	Circuits protected
F37	30	Rear Gate Trunk Module (RGTM)
F38	40	Driver front Seat Module (DSM) Heating, Ventilation and Air Conditioning (HVAC) control module
F40	40	Not used
F41	25	Rear sliding window motor
F42	30	Trailer Brake Control Module (TBM) Trailer Module (TRM)
F47	50 Gas	Cooling fan motor 1
F48	20	Heated rear seat module
F49	50	Cooling fan motor 2
F50	40	Rear window defrost grid
F55	30 park	Trailer tow connector Trailer Module (TRM)
F56	20 stop turn	Trailer tow connector Trailer Module (TRM)
F58	10 reverse	Trailer tow connector