

Module Name	Over the Air Update Programing Capable (Yes/N0)	Module Update Method
ABS module	Yes	ABA swap
ACCM	Yes	ABA swap
ACM	No	N/A
APIM	Yes	ABA swap
ATCM	Yes	Erase and Replace
BCM	Yes	Erase and Replace
BCMC [BJB]	Yes	Erase and Replace
BECM	Yes	Erase and Replace
CCM	Yes	ABA swap
CMR_DSMC (Driver status monitor camera)	Yes	ABA swap
DCACA	Yes	Erase and Replace
DCDC	Yes	Erase and Replace
DDM	Yes	Erase and Replace
DSM / RBM	Yes	Erase and Replace
DSP	No	Erase and Replace
GSM	No	N/A
GWM	Yes	ABA swap
HCM	Yes	Erase and Replace
HVAC module	Yes	ABA swap
IPC	Yes	ABA swap
IPMA - ADAS	Yes	ABA swap
Lithium-Ion Storage Battery (LISB)	No	Erase and Replace
OCS module	No	N/A
PACM	Yes	Erase and Replace
PCM	Yes	ABA swap
PCM (Diesel)	No	N/A
PDM	Yes	Erase and Replace

PSCM	Yes	Erase and Replace
RCM	Yes	Erase and Replace
RGTM	No	Erase and Replace
RTM	Yes	Erase and Replace
SASM	No	N/A
SCCM	Yes	Erase and Replace
SCMG	Yes	Erase and Replace
SCMH	Yes	Erase and Replace
SECM	No	N/A
SOBDMC	Yes	ABA swap
SODCMC	Yes	ABA swap
SODCMD	Yes	ABA swap
SODL	Yes	ABA swap
SODR	Yes	ABA swap
TCCM	No	N/A
TCM	No	N/A
TCU	Yes	ABA swap
TRM / TBM	Yes	Erase and Replace
WACM	No	N/A

OTA & Connected Vehicle Dashboard

PTS has a Connected Vehicle tab that allows access to details of the Over the Air (OTA) update status of the vehicle. The dashboard contains a calendar with a 60 day history of the Over the air update activity on the vehicle and a Currently In Process dashboard. The calendar contains but is not limited to the information listed below.

- The update ID
- The data and time each update was attempted
- The module(s) receiving the update
- If any DTCs were cleared after the update
- The connectivity methods allowed for each update
- Release notes for each of the updates